Infiniium 9000 Series Oscilloscopes





Data Sheet





Engineered for broadest measurement capability



If you haven't purchased an Agilent scope lately, why should you consider one now?

If you're like most engineers, you never know what your next project will demand from you. You need an oscilloscope that can adapt to a wide variety of debug and test challenges.

That's why we designed our new Infiniium 9000 Series oscilloscope to meet a full range of needs.


First we built in the powerful features you'd expect in any Infiniium scope. Then we engineered the scope for the broadest measurement capability, so it would be the most indispensable tool in your arsenal.

There is no better way to experience the superiority of the Infiniium 9000 Series scopes than to see it.

Contact Agilent today to request an evaluation.

Or visit:

www.agilent.com/find/9000




The Infiniium 9000 Series offers bandwidths up to 4 GHz. Each model, equipped with a large 15" XGA LCD display, comes in a whisper-quiet package that is just 9" (23 cm) deep and weighs only 26 pounds (11.8 kg).

Model	Analog bandwidth	Analog sample rate 4-channel/2-channel	Standard memory 4-channel/2-channel	Scope channels	Logic channels
DSO9064A	600 MHz	5 GSa/s/10 GSa/s	20 Mpts/40Mpts	4	-
MS09064A	600 MHz	5 GSa/s/10 GSa/s	20 Mpts/40Mpts	4	16
DS09104A	1 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	-
MS09104A	1 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	16
DS09254A	2.5 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	-
MS09254A	2.5 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	16
DS09404A	4 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	-
MS09404A	4 GHz	10 GSa/s/20 GSa/s	20 Mpts/40Mpts	4	16

What makes the Infiniium 9000 Series the go-to scope for a whole range of test and debug challenges?


It's three instruments in one

- 1. Scope: The powerful features of our Infiniium Series oscilloscopes coupled with superior specifications give you precise signal representation.
- 2. Logic analyzer: Fast deep-memory digital channels let you see critical data values and timing relationships.
- 3. Protocol analyzer: The world's first scope-based protocol viewer with multi-tab viewing. Quickly drill and move between protocol and physical layers.



It offers the widest range of debug and compliance application software

Need accurate answers to your measurement questions? The Infiniium 9000 Series offers the largest range of application-specific software for debug, analysis and compliance testing. Which application is right for you? Take a look at the possibilities on pages 7-12.



It's sized to fit your environment

Limited bench space? It has a small footprint and thin profile Height: 12.9" (33 cm); width: 16.8" (43 cm); depth: just 9" (23 cm)

Need to share the scope? It's light weight: 26 lbs. (11.8 kg)

Need to see lots of signals? It has the biggest screen: 15" (23 cm) XGA







It's three instruments in one

1. Oscilloscope

High-performance scope channels ensure superior viewing of signals under test. All models incorporate a powerful, feature-packed Infinitum oscilloscope with responsive deep memory.




Up to 4 GHz bandwidth and 20 GSa/s high sample rates guarantee you'll see a precise representation of the analog characteristics of signals you're testing.



Mask tests, histograms and a wide variety of functions provide deep signal analysis.


Responsive deep memory

With standard 20 Mpts/ch, and up to 1 Gpts/ch of memory, you can capture long time periods while retaining fast sample rates. Fast update rates mean your scope stays responsive with deep memory on, ensuring precise representation of analog signals.




Advanced triggering

Advanced triggers are essential when you are investigating suspected problems. Infiniium offers a full range of advanced triggers to help you isolate and capture the condition you need to characterize. The 9000 Series simplifies trigger setups by using intuitive dialog boxes with descriptive graphics.



Drag and drop measurements

It's simple: drag an icon from the measurement bar and drop it on the cycle you want to measure. You can make up to ten measurements on your waveforms. All of the measurements appear at the bottom of the display with statistics and are color-coded to the channel you are measuring.



It's three instruments in one

2. Logic analyzer

MSO models add 16 high-speed timing channels with standard 128 Mpts digital memory, allowing you to retain fast 2 GSa/s sample rates over long periods of time.



Use the timing channels to evaluate control signal relationships and data buses up to 16 bits wide. Use symbols to more quickly interpret waveforms.



Designing with Altera or Xilinx FPGAs? Use the FPGA dynamic probe for rapid internal FPGA measurements. Using I²C, SPI, RS-232, or low- or full-speed USB? Use the digital channels to acquire and decode these buses, preserving analog channels for other time-correlated measurements.


Digital and mixed-signal trigger

Trigger on and display individual signals or buses. With precise time-correlation between analog and digital signals, confidently trigger across any combination of analog and digital signals simultaneously.




Industry's only segmented memory for both analog and digital channels

Capture short bursts without consuming memory during periods when the trigger condition is not met. Agilent is the only vendor that supports segmented memory capture on both analog and digital channels.



Waveform and Listing Windows

View buses as waveforms or easily follow events in the listing window expandable to the entire display. A blue tracking marker provides time-correlation between waveform and listing displays.



It's three instruments in one

3. Protocol analyzer

Does your design include a serial bus that is a key point for testing or debugging? Add protocol analysis capability to your scope for:

· CAN

FlexRay

· I²C

JTAG

• LIN

• MIPI D-Phy

• PCle

· RS-232/UART


SATA

· SPI

· USB

·8B/10B


· digRF




Quickly move between physical and protocol layer information using the time-correlated tracking marker. Display protocol content using waveform symbols and the industry's first multi-tab protocol viewer. The packets tab shows a high level view of the packet over time.



Protocol-level triggering makes it easy to isolate events with pinpoint accuracy.



Use any combination of analog or digital channels for serial protocol decode, with up to four buses decoded simultaneously.



Header tab shows packets in a databook format. Hovering on any tab reveals additional detail.

Widest range of debug and compliance software applications: serial protocol-level




Trigger and view on-screen serial decode of I²C packets.

I²C/SPI serial trigger and decode (N5391B or Option 007 on new scope purchases)

This application displays real-time time-aligned decode of I²C and SPI serial buses. Hardware-based triggering means triggering reliably, even on the most infrequent events.

This application works on all models and can use any combination of scope or logic acquisition channels.

For more information: www.agilent.com/find/9000 I2C-SPI



Trigger on and decode RS-232/UART transmission.

RS-232/UART serial decode and trigger (N5462B or Option 001 on new scope purchases)

This application eliminates the need to manually decode bus traffic. Using data captured on the scope or logic channels, the application lets you easily view the information sent over an RS-232 RS-422, RS-485 or other UART serial buses.

Display real-time time-aligned decode of transmit and receive lines. Hardware-based triggering means triggering reliably, even on the most infrequent events.

This application works on all models and can use any combination of the scope or logic acquisition channels.

For more information: www.agilent.com/find/9000 RS-232



Trigger on and decode CAN, LIN and FlexRay serial packets.

CAN, LIN and FlexRay triggering and decode (N8803B or Option 008 on new scope purchases)

Trigger on and view both protocol layer information and physical layer signal characteristics for CAN, LIN and FlexRay buses. Numerical decode values are automatically displayed and synchronized below the captured signal or seen in protocol viewer.

Hardware-based triggering for CAN and LIN means triggering reliably, even on the most infrequent events. FlexRay uses software-based protocol triggering.

This application works on all models and can use any combination of scope or logic acquisition channels.

For more information: www.agilent.com/find/9000 CAN



Import BSDL files and decode JTAG scan chain activity.

JTAG (IEEE 1149.1) triggering and decode (N8817A or Option 042 on new scope purchases)

This application displays real-time time-aligned decode of JTAG (IEEE 1149.1) TDI and TDO signals. The application eliminate the difficult task of manually determining JTAG TAP controller states, instruction and data register decode, and flags error conditions. The application includes scan chain description features including the ability to import .bsdl files for each device and displays device names and opcodes in the protocol listing.

This application works on all models and can use any combination of scope or logic acquisition channels.

For more information: www.agilent.com/find/9000_JTAG

Widest range of debug and compliance software applications: serial protocol and FPGA



Trigger on and decode USB packets.

USB serial trigger and protocol viewer (N5464B or Option 005 on new scope purchases)

Trigger on and quickly view USB packets, payload, header and detail information. Powerful time-correlated views of waveform and symbol, to the bit level, make it easy to isolate communication faults to logic or analog sources.

USB hardware-based triggering means triggering reliably, even on the most infrequent events.

Low and full-speed USB protocol is supported on digital and scope channels of all models.

High-speed USB protocol is supported on scope channels of 1 GHz, 2.5 GHz and 4 GHz models.

For more information: www.agilent.com/find/9000 USB



Trigger on and decode MIPI packets

MIPI D-Phy serial decode and trigger (N8802A or Option 019 on new scope purchases)

This application eliminates the need to manually decode bus traffic. Using data captured on the scope, the application lets you easily view the information sent over MIPI serial buses.

The application also enables software-based protocol triggering.

This application works on all 4 GHz models and can use any combination of the scope channels

For more information: www.agilent.com/find/N8802A



Trigger on and decode PCIe serial packets.

PCI Express® serial trigger and protocol viewer (N5463B or Option 006 on new scope purchases)

This application provides protocol-level triggering and viewing of a PCle® lane. Quickly view packets, payload, header, and detail information. Powerful time-correlated views of waveform, symbol, character, link and transaction layer packet data down to the bit level make it easy to isolate communication faults to logic or analog sources.

Trigger on and view CRC, 8B/10B and disparity errors. Hardware-based triggering for PCIe means triggering reliably, even on the most infrequent events.

This application is supported on scope channels of 4 GHz models.

For more information: www.agilent.com/find/9000_PCI



Trigger on and decode SATA serial packets


SATA triggering and decode (N8801A or option 038 on new scope purchases)

Trigger on and view both protocol layer information and physical layer signal characteristics for SATA 1 (1.5 GB/s). Numerical decode values are automatically displayed and synchronized below the capture signal or seen in protocol viewer.

This application enables software-based protocol triggering. This application works on 4 GHz and can use any combination of scope channels

For more information: www.agilent.com/find/N8801A

Widest range of debug and compliance software applications: serial physical-layer




Check for USB compliance.

USB 2.0 compliance testing (N5416A or Option 029 on new scope purchases)

Quickly determine USB compliance with this USB-IF recognized solution. A setup wizard guides you through test selection and configuration.

This application is USB-IF approved and supported on all 2.5 GHz and 4 GHz models.

For more information: www.aqilent.com/find/9000 USB-compliance




Test DDR memory.

DDR1 and LPDDR/DDR2 and LPDDR2/DDR3 compliance testing (U7233A/N5413B/U7231A or Options 031/032/033 on new scope purchases) or N5459A Opt 001 for all memory applications

Quickly and easily evaluate and characterize your memory designs. Automated testing based on JEDEC specifications saves time. The application also includes additional debug and compliance capabilities.

This application is supported on all models. However, the DDR technology you are using may dictate the minimal bandwidth required for your scope.

For more information: www.agilent.com/find/9000 DDR




Validate Ethernet compliance.

Ethernet compliance testing (N5392A or Option 021 on new scope purchases)

Perform a wide range of electrical tests for 10-, 100-, and 1000-Base-T systems. An N5395C test fixture and N5396A jitter test cable speed compliance testing.

This application is supported on all 600 MHz and higher bandwidth models.

For more information: www.agilent.com/find/9000 ethernet



Check for MIPI compliance.


MIPI compliance testing (U7238A or Option 035 on new scope purchased)

Quickly validate your embedded D-Phy data link for CSI and DSI architectures. This software performs a wide range of tests required for meeting MIPI D-Phy physical layer requirements.

This application is supported on analog channels of all 4 GHz models.

For more information: www.agilent.com/find/U7238A

Widest range of debug and compliance software applications: InfiniiScan and jitter analysis



Identify signal integrity issues with InfiniiScan Zone – Qualify triggering.

InfiniiScan event identification (N5415B or Option 009 on new scope purchases)

Rapidly trigger on complex events and identify signal integrity issues.

This innovative software quickly scans through thousands of acquired waveform cycles and isolates anomalous signal behavior. Up to eight zones across channels are available.

This application is supported on all models.

For more information: www.agilent.com/find/infiniiScan



Conduct jitter analysis.

EZJIT analysis software (E2681A or option 002 on new scope purchases)

Quickly characterize and evaluate most commonly needed jitter measurements, including cycle-cycle, N-cycle, period, time-interval, error, setup and hold time, histograms, measurement trending and jitter spectrum.

This application is supported on all models.

For more information: www.agilent.com/find/EZJIT




Analyze jitter plus RJ/DJ separation.

EZJIT Plus analysis software (N5400A or Option 004 on new scope purchases. To upgrade from EZJIT to EZJIT Plus, order N5401A.)

EZJIT Plus adds additional compliance views and an expanded measurement setup wizard to simplify and automate RJ/DJ separation for testing against industry standards.

This application is supported on all models.

For more information: www.agilent.com/find/EZJITPlus



Recover embedded clocks with serial data analysis (SDA).

High-speed serial data analysis software (N5384A or Option 003 on new scope purchases)

Quickly validate signal integrity for high-speed serial interfaces with embedded clocks. Recover embedded clocks synchronized with the analog waveform view. Build and validate eye diagrams.

The SDA package also includes software-based bit-level triggering and decode for 8B/10B.

This application is supported on all models.

For more information: www.agilent.com/find/9000_SDA

Widest range of debug and compliance software applications: viewing and analysis



Use vector signal analysis software to see FFT-based spectrum analysis.

Vector signal analysis software (89601B)

Expand the measurement capability of your scope with the 89601B vector signal analysis software. This advanced DSP-based software takes the digitized signal data from the scope. Then it provides FFT-based spectrum analysis and wide-bandwidth digital modulation analysis for wireless communication signals such as WCDMA and cdma2000 and wireless networking signals such as 802.11 WiFi and 802.16 WiMax.

Take advantage of the super-wide bandwidth of your scope to capture and evaluate radar signals.

For more information: www.agilent.com/find/VSA



Prove your designs conform to industry standards with a communication mask test kit.


Communication mask test kit (E2625A)

Take the frustration out of communications testing and prove your designs conform to industry standards with the communication mask test kit option.

The kit comes with a set of electrical communication adapters to ensure convenient, reliable, and accurate connections to your device under test. The kit includes more than 20 industry-standard ANSI T1.102, ITU-T G.703, and IEEE 802.3 communication signal mask templates.

This application is supported on all models.

For more information: www.agilent.com/find/9000_comm




Signal equalization using user-defined function.

User-defined function (N5430A or Option 010 on new scope purchases)

Install MATLAB $^{\otimes}$ on your scope and add your favorite MATLAB .m scripts as function operators and use them as standard waveform functions.

This application is supported on all models and requires MATLAB software (not included with UDF)

For more information: www.agilent.com/find/UDF



Quickly automate oscilloscope measurements.

User-definable application (N5467A or Option 040 on new scope purchases)

Rapidly develop your own automated measurements and tests. This application provides the framework you need to quickly program and automate any single or set of measurements the oscilloscope can make.

The application also provides full control of other Agilent instruments and HTML reporting capabilities.

For more information: www.agilent.com/find/9000 UDA

Infiniium 9000 Series applications and upgrades




Rapid FPGA debug.

FPGA dynamic probe application (N5397A or Option 016 on new scope purchases)

Agilent's MSO FPGA dynamic probe provides internal FPGA visibility and quick instrument setup using an innovative core-assisted debug approach. Measurement tasks that previously took hours can be done in seconds with a few mouse clicks.

This application is supported on all MSO models.

For more information: www.agilent.com/find/9000 xilinx



Use your scope to quickly make and analyze power measurements.

Power application (U1882A or Option 015 on new scope purchases)

Agilent's power application provides a full suite of power measurements. Make more accurate power-supply efficiency measurements by using an U1880A de-skew fixture to de-skew your voltage and current probes.

This application is supported on all models.

For more information: www.agilent.com/find/9000_power-app



Quickly characterize and correct for any input to your oscilloscope

PrecisionProbe software (N2808A)

Make more accurate measurements independent of what probes or cables used. Agilent's N2808A PrecisionProbe software characterizes and corrects for the loss in your specific cable or probe. PrecisionProbe removes the uncertainty about the input connected to your oscilloscope by allowing you to see its characteristics in less than five minute. PrecisionProbe gives you design and debug confidence by allowing you to quickly de-embed probe and cable loss to make more accurate measurements.

For more information: www.agilent.com/find/PrecisionProbe




InfiniiView Oscilloscope Analysis Software (N8900A)

Wish you could do additional signal viewing, analysis and documentation tasks away from your scope and target system? With Agilent's InfiniiView oscilloscope analysis software you can. Capture waveforms on your scope, save to a file, and open the data record into Agilent's InfiniiView application. View, analyze, share, and document scope measurements anywhere your PC goes.

Agilent Infiniium portfolio

Agilent's real-time Infiniium lineup includes 9000, 9000 H-, 90000A and 90000 X Series oscilloscopes. These share a number of advanced hardware and software technology blocks. Use the following selection guide to determine which best matches your specific needs.







See your signals in HD









Fastest real-time oscilloscope

	9000 Series	9000 H-Series	90000 Series	90000 X-Series	90000 Q-Series
600 MHz and 1 GHz bandwidth	•	•			
2.5 GHz and 4 GHz bandwidth	•		•		
Bandwidth upgradability	Up to 4 GHz	•	Up to 13 GHz	Up to 62 GHz	Up to 62 GHz
50 Ω & 1 MΩ inputs	•	•	1 M Ω with adapter	1 M Ω with adapter	1 M Ω with adapter
MSO models	•	•			
Max 2-channel (4-channel) sample rate	20 GSa/s (10 GSa/s)	10 GSa/s (10 GSa/s)	40 GSa/s (40 GSa/s)	80 GSa/s (40 GSa/s)	160 GSa/s (80 GSa/s)
GPIB	N4865A GPIB to LAN adapter	N4865A GPIB to LAN adapter	Built in option	Built in option	Built in option
Rackmount height	8U	8U	7U	7U	8U
Display size	15"	15"	12"	12"	15"



Agilent Infiniium 9000 Series oscilloscopes





Dedicated **single acquisition button** provides better control to capture a unique event.

Pressing horizontal delay knob sets the delay to zero. A **zoom button** provides quick access to two screen-zoom modes.

MegaZoom instant response and optimum resolution allows you to pan and zoom quickly.

Autoscale lets you rapidly display any analog or digital active signals, automatically setting the vertical, horizontal and trigger controls for the best display, while optimizing memory.

Digital channel button provides quick setup access.

Serial decode button enables quick setup access.

Dedicated per-channel front panel controls make it easy to access the vertical and horizontal scaling and offset.

Quick access to fine/vernier control by pressing the horizontal and vertical sensitivity knobs.

AutoProbe interface automatically configures the attenuation ratio of the probe and provides probe power for Agilent's active probes.

to save your work and update your system software quickly.



Accessory pouch detaches easily.

Connectivity and probing

Connectivity

Industry compatibility

Export screen shots and waveforms in numerous industry-standard formats. In addition, the 9000 Series supports compatibility with the following

- MATLAB Basic and Advanced (add as 061 and 062 on new scope orders)
- IVI COM driver for application development environments such as Visual Studio, Agilent VEE, NI LabView and MATLAB instrument control toolbox.

www.agilent.com/find/adn

- IntuiLink tool bars and data capture.
 www.agilent.com/find/intuilink
- · LXI Class C including built-in Web control
- NI LabView PnP and IVI drives www.agilent.com/find/ni9404

Probing

Each Infiniium 9000 Series oscilloscope ships with four N2873A 10:1 divider passive probes and probe accessory pouch.

With both 50 Ω and 1 M Ω inputs, Infiniium 9000 Series scopes support a wide range of probes, including Agilent's InfiniiMax and InfiniiMode Series probes.

Agilent offers an innovative family of probes that are engineered for signal access and measurement accuracy. Whether you're looking for simple passive probes, the high bandwidth and low loading of an active probe, or specialty probes for current or high voltage, we can meet your needs. Our innovative accessories allow reliable connection to challenging

components like small pitch devices, surface mount ICs, and DDR BGA packages — even hands free! To see our entire award-winning portfolio of passive, single-ended active, differential active, and current probes for Infiniium oscilloscopes, please view the Infiniium Oscilloscope Probes and Accessories Selection Guide. publication number 5968-7141EN.



Recommended optional active probes

DSO/MSO9404A 1132A InfiniiMax 5 GHz probe N2752A InfiniiMode 6 GHz probe

DSO/MSO9254A 1131A InfiniiMax 3.5 GHz probe

N2751A InfiniiMode 3.5 GHz probe DSO/MSO9104A N2796A 2 GHz single-ended probe 1130A InfiniiMax 1.5 GHz probe

N2750A InfiniiMode 1.5 GHz probe DSO/MSO9064A N2795A 1 GHz single-ended probe N2750A InfiniiMode 1.5 GHz probe







Vertical: scope channels	9064A	9104A	9254A	9404A			
Analog bandwidth (–3 dB) 50 Ω^1	600 MHz	1.0 GHz	2.5 GHz	4 GHz			
1ΜΩ	500 MHz	500 MHz	500 MHz	500 MHz			
Typical Rise Time / Fall	540 ps	253 ps	142 ps	85 ps			
Time 10% to 90% at 50 Ω							
Typical Rise Time / Fall	360 ps	174 ps	98 ps	59 ps			
Time 20% to 80% at 50 Ω							
Input channels	DSO9000 - 4	-					
	MS09000 – 4 analog + 16 digital						
Input impedance ¹	50 Ω ± 2.5%,	1 MΩ ± 1% (11pF ty	vpical)				
Input sensitivity ³	1 MΩ: 1 mV/c	div to 5 V/div					
	50 Ω: 1 mV/div to 1 V/div						
Input coupling	1 MΩ: AC (3.5	1 MΩ: AC (3.5 Hz), DC					
	50 Ω:DC						
Bandwidth limit	20 MHz on 1 I	MΩ input ; 500 MH	z up to full scope bar	ndwidth in increments of 500 MHz			
Vertical resolution ^{2,3}	8 bits, ≥12 bit	s with averaging					
Channel-to-channel isolation	DC to 50 MHz: 50 dB						
	>50 MHz to 2						
	>2.5 GHz to 4	GHz: 25 dB					
DC gain accuracy ^{1,2,3}	± 2% of full so	cale at full resolution	on on channel scale :	± 5 °C from cal temp			
Maximum input voltage ¹	1 MΩ: 150V R	MS or DC, CAT I					
	± 250 V (DC + AC) in AC coupling						
	50 Ω: 5 Vrms						
Offset range	Vertical sensi	tivity		Available offset			
1 ΜΩ	1 mV to <10 n	nV/div		± 2 V			
	10 mV to <20	mV/div		± 5 V			
	20 mV to <10	0 mV/div		± 10 V			
	100 mV to <1	V/div		± 20 V			
	1 V to 5 V/div	,		± 100 V			
50 Ω				±12 div or ±4V, whichever is smallest			

¹ Denotes warranted specifications, all others are typical. Specifications are valid after a 30-minute warm-up period and ±5 °C from firmware calibration temperature. Input impedance is valid when V/div scaling is adjusted to show all waveform vertical values within scope display.

² Vertical resolution for 8 bits = 0.4% of full scale, for 12 bits = 0.024% of full scale.

^{3 50}Ω input: Full scale is defined as 8 vertical divisions. Magnification is used below 10mV/div, full-scale is defined as 80 mV. The major scale settings are 5mV, 10mV, 20mV, 50 mV, 100mV, 200 mV, 500 mV, 100mV, 500 mV, 5

 $¹M\Omega$ input: Full scale is defined as 8 vertical divisions. Magnification is used below 5mV/div, full-scale is defined as 40 mV. The major scale settings are 5mV, 10mV, 20mV, 50mV, 100mV, 200mV, 500mV, 100mV, 100mV,

Vertical: scope channels (con't)

Offset accuracy ^{1,3}	± (1.25% of cha	annel offset +1% of full scale + 1 mV)
Dynamic range		rom center screen om center screen
DC voltage measurement accuracy ²		
	Dual cursor Single cursor	<pre>± [(DC gain accuracy)+(resolution)] ± [(DC gain accuracy)+(offset accuracy)+(resolution/2)]</pre>

RMS Noise Floor (V _{RMS AC})

		9064A	91	04A	92	54A	94	04A
Volts/div	full BW	500 MHz filter	full BW	1 GHz filter	full BW	2 GHz filter	full BW	4 GHz filter
10 mV	213 uV	138 uV	240 uV	120 uV	273 uV	210 uV	402 uV	263 uV
20 mV	470 uV	175 uV	481 uV	154 uV	445 uV	330 uV	627 uV	424 uV
50 mV	1.15 mV	.464 mV	1.24 mV	.415 mV	1.22 mV	.780 mV	1.67 mV	1.12 mV
100 mV	2.37 mV	.895 mV	2.43 mV	.786 mV	2.54 mV	1.50 mV	3.17 mV	2.16 mV
200 mV	4.65 mV	1.75 mV	4,85 mV	1.50 mV	5.06 mV	2.86 mV	6.18 mV	4.15 mV
500 mV	11.8 mV	4.60 mV	12.3 mV	4.15 mV	12.2 mV	7.61 mV	15.8 mV	11.26 mV
1 V	23.9 mV	8.91 mV	24.3 mV	7.85 mV	25.2 mV	14.9 mV	31.5 mV	21.9 mV

Vertical: digital channels	On all MSO Models
Input channels	16 digital channels
Threshold groupings	16 digital channels Pod 2: D15 – D8
Threshold selections	TTL (1.4V), CMOS, (5.0V, 3.3V, 2.5V), ECL (-1.3V), PECL (3.7V), user defined (±8.00 V in 100 mV increments)
Maximum input voltage	±40 V peak CAT I
Threshold accuracy	±(100 mV + 3% of threshold setting)
Input dynamic range	±10 V about threshold
Minimum input voltage swing	500 mV peak-to-peak
Input impedance (flying leads)	100 k Ω ± 2% (~ 8 pF) at probe tip
Resolution	1 bit
Analog bandwidth	400 MHz

¹ Denotes warranted specifications, all others are typical. Specifications are valid after a 30-minute warm-up period and ± 5 °C from firmware calibration temperature. 2 Vertical resolution for 8 bits = 0.4% of full scale, for 12 bits = 0.024% of full scale.

^{3 50}Ω input: Full scale is defined as 8 vertical divisions. Magnification is used below 10mV/div, full-scale is defined as 80 mV. The major scale settings are 5mV, 10mV, 20mV, 50 mV, 100 mV, 200 mV, 500 mV, 1V.

 $¹M\Omega$ input: Full scale is defined as 8 vertical divisions. Magnification is used below 5mV/div, full-scale is defined as 40 mV. The major scale settings are 5mV, 10mV, 20mV, 50 mV, 100 mV, 200 mV, 500mV, 100 mV, 200 mV, 500mV, 100 mV, 100

Horizontal

Channel-to-channel skew (digital)	2 ns typical	
Glitch detect (digital)	≥ 2.0 ns	
Main time base range	5 ps/div to 20 s/div	
Horizontal position range	0 to ± 200 s	
Delayed sweep range	1 ps/div to current main time base setting	
Resolution	1 ps	
Modes	Main, delayed, roll (200 ms to 20 sec)	
Reference positions	Left, center, right	
Channel deskew	- 1 ms to +1 ms range	
Time scale accuracy	\pm (0.4 + 0.5 * YrsSinceCal) ppm pk	
Delta-time measurement accuracy ^{2,3,4,5}		x= y=
Absolute averaging disabled	$\sqrt{\left(\frac{x*Noise}{SlewRate}\right)^2 + y*10^{-24} + \frac{TimeScaleAccy \cdot Reading}{2}} \text{ sec pk}$	9064 4.8 20 9104 4.8 15 9254 4.0 15 9404 5.0 20
Absolute >256 averages	$\sqrt{\left(\frac{x * Noise}{SlewRate}\right)^2 + y * 10^{-24} + \frac{TimeScaleAccy \cdot Reading}{2}} $ sec pk	9254 .33 .10 9404 .35 .15
Standard deviation averaging disabled	$\sqrt{\left(\frac{1.4*Noise}{SlewRate}\right)^2 + y*10^{-24} sec_{rms}}$	9064 .75 9104 .65 9254 .75 9404 .80
Standard deviation >256 averages	$\sqrt{\left(\frac{0.1*Noise}{SlewRate}\right)^2 + 0.01*10^{-24}} \sec_{rms}$	
Jitter measurements floor ^{2,3}		x= y= 9064 1.0 1.0
Time interval error ⁴	$\sqrt{\left(\frac{x*Noise}{SlewRate}\right)^2 + y*10^{-24} + sec_{rms}}$	9104 1.0 0.5 9254 .95 1.1 9404 .95 1.2
Period jitter	$\sqrt{\left(\frac{1.4*Noise}{SlewRate}\right)^2 + y*10^{-24} sec_{rms}}$	y= 9064 .75 9104 .65 9254 .75 9404 .80
N-cycle, cycle-cycle jitter	$\sqrt{\left(\frac{2.4*Noise}{SlewRate}\right)^2 + y *10^{-24}} \operatorname{sec}_{rms}$	y= 9064 1.8 9104 1.4 9254 1.9 9404 2.0

¹ Denotes warranted specifications, all others are typical. Specifications are valid after a 30-minute warm-up period and ±5 °C from firmware calibration temperature.

² Noise is the displayed noise floor. SlewRate is the displayed slew rate of the signal at the threshold crossings. Sample rate = max, sin(x)/x interpolation enabled.

³ Measurement threshold = fixed voltage at 50% level.

⁴ Time ranges \leq 10 $\mu s.$

⁵ Values represent time error between two edges on a single channel. Standard deviation value refers to the standard deviation of 256 consecutive measurements performed using an individual instrument. Reading is the displayed DTMA measurement value.

Acquisition	9104, 9254, 9404	9064
Maximum real-time sample rate	4 ch x 10 GS/s or 2 ch x 20 GS/	s 4 ch x 5 GSa/s or 2 ch x 10 GSa/s
Memory depth per channel Standard Option 50M Option 100 Option 200 Option 500	20 Mpts on 4 channels, 40 Mpts 50 Mpts on 4 channels, 100 Mp 100 Mpts on 4 channels, 200 M 200 Mpts on 4 channels, 400 M 500 Mpts/ 250 Mpts on 4 chann	s on 2 channels ots on 2 channels
Maximum time between triggers	0 sec.) or resolution yields a maximum effe resolution between segments) ts standard memory, up to 131,072 s s is 562,950 seconds (6.5 days)	ctive sample rate of 1,000 GSa/s)
Filters	Sin (x) / x Interpolation	
Acquisition: digital channels		
Maximum real time sample rate	2 GSa/s	
Maximum memory depth per channel	128/ 64 Mpts with 2 GSa/s. 64/	32 Mpts with sampling < 2 GSa/s (single/repetitive mode).
Minimum width glitch detection	2 ns	
<u> </u>	2 ns	
Trigger: scope channels	2 ns Channel 1, channel 2, channel 3	, channel 4, aux, and line
Minimum width glitch detection Trigger: scope channels Trigger sources Sensitivity		DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div 2 GHz to 4 GHz: 1.0 div
Trigger: scope channels Trigger sources	Channel 1, channel 2, channel 3	DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div
Trigger: scope channels Trigger sources Sensitivity	Channel 1, channel 2, channel 3 1 $M\Omega$ input, edge trigger, 50 Ω	DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div 2 GHz to 4 GHz: 1.0 div DC to 700 MHz: 300 mVp-p div from center screen (50 Ω) div from center screen (1 MΩ)
Trigger: scope channels Trigger sources Sensitivity Trigger level range Channel 1,2,3,4	Channel 1, channel 2, channel 3 1 $M\Omega$ input, edge trigger, 50 Ω Auxiliary \pm 8 V @ 5 V /div, $<$ 5 V /div \pm 4 \pm 8 V @ 5 V /div, $<$ 5 V /div \pm 8	DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div 2 GHz to 4 GHz: 1.0 div DC to 700 MHz: 300 mVp-p div from center screen (50 Ω) div from center screen (1 MΩ)
Trigger: scope channels Trigger sources Sensitivity Trigger level range Channel 1,2,3,4 Auxiliary Sweep modes	Channel 1, channel 2, channel 3 1 M Ω input, edge trigger, 50 Ω Auxiliary \pm 8 V @ 5 V/div, < 5 V/div \pm 4 \pm 8 V @ 5 V/div, < 5 V/div \pm 8 \pm 5 V (50 Ω up to 500 MHz with	DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div 2 GHz to 4 GHz: 1.0 div DC to 700 MHz: 300 mVp-p div from center screen (50 Ω) div from center screen (1 M Ω) at least 500 mV signal swing) $\frac{\gamma = \frac{1}{9064}}{\frac{9104}{35}}$ sec $_{rms}$
Trigger: scope channels Trigger sources Sensitivity Trigger level range Channel 1,2,3,4 Auxiliary	Channel 1, channel 2, channel 3 1 M Ω input, edge trigger, 50 Ω Auxiliary \pm 8 V @ 5 V/div, < 5 V/div \pm 4 \pm 8 V @ 5 V/div, < 5 V/div \pm 8 \pm 5 V (50 Ω up to 500 MHz with Auto, triggered, single	DC to 500 MHz: 0.6 div DC to 2 GHz, 0.5 div 2 GHz to 4 GHz: 1.0 div DC to 700 MHz: 300 mVp-p div from center screen (50 Ω) div from center screen (1 M Ω) at least 500 mV signal swing) $\frac{\gamma = \frac{1}{9064}}{\frac{9104}{35}}$ sec $_{rms}$

^{1.} Internal edge trigger mode. Trigger threshold = fixed voltage at 50% level. The slew rate independent value in the formula represents the traditional trigger jitter.

^{2.} Display jitter example. At 100 mV/div typical noise values are 3.2 mV RMS for 9404 models, 2.5 mV RMS for 9254A models, and 2.4 mV RMS for 9104A models. For slew rate of 500 mVpp sin wave with frequency equal to max analog bandwidth of each model, typical display jitter is .95 ps RMS for 9404A models, .97ps for 9254A models, and 1.7 ps RMS for 9104A models.

Trigger: digital channels MSO Models

Threshold range (user defined)	±8.0 V in 100-mV increments
Threshold accuracy	\pm (100 mV + 3% of threshold setting)

Measurements and math

Measurements and math	
Waveform measurements	(can be made on either min or zoom window with up to 10 simultaneous measurements with statistics)
Voltage (scope channels)	Peak-to-peak, minimum, maximum, average, RMS, amplitude, base, top, overshoot, V overshoot, preshoot, V preshoot, upper, middle, lower, crossing point voltage, pulse top, pulse base, pulse amplitude
Time (digital channels)	Period, frequency, positive width, negative width, duty cycle, delta time
Time (scope channels)	Rise time, fall time, period, frequency, positive width, negative width, duty cycle, Tmin, Tmax, Tvolt, channel-to-channel delta time, channel-to-channel phase, count pulses, burst width, burst period, burst interval, setup time, hold time
Mixed (scope channels only)	Area, slew rate
Frequency domain	FFT frequency, FFT magnitude, FFT delta frequency, FFT delta magnitude
Level qualification	Any channels that are not involved in a measurement can be used to level-qualify all timing measurements
Eye-diagram measurements	Eye height, eye width, eye jitter, crossing percentage, Q factor, and duty-cycle distortion
Measurement modes	
Statistics	Displays the mean, standard deviation, minimum, maximum range, and number of measurement values for the displayed automatic measurements
Histograms (scope channels)	
Source	Waveform or measurement (histogram on measurement requires EZJIT or EZJIT+ option)
Orientation	Vertical (for timing and jitter measurements) or horizontal (noise and amplitude change) modes, regions are defined using waveform markers
Measurements	Mean, standard deviation, mean \pm 1, 2, and 3 sigma, median, mode, peak-to-peak, min, max, total hits, peak (area of most hits), X scale hits, and X offset hits
Marker modes	Manual markers, track waveform data, track measurements
Waveform math	
Number of functions	Four
Operators	Absolute value, add, average, Butterworth ² , common mode, differentiate, divide, FFT magnitude, FFT phase, FIR ¹¹ , high pass filter, integrate, invert, LFE ² , low pass filter (4th-order Bessel Thompson filter), magnify, max, min, multiply, RT Eye ² , smoothing, SqrtSumOfSquare ² , square, square root, subtract, versus Chartstate (MSO models), charttiming (MSO models)
Automatic measurements	Measure menu access to all measurements, ten measurements can be displayed simultaneously
Multipurpose	Front-panel button activates up to ten pre-selected or ten user-defined automatic measurements
Drag-and-drop	Measurement toolbar with common measurement icons that can be dragged and dropped onto the
measurement toolbar	displayed waveforms
FFT	
Frequency range	DC to 10 GHz (at 20 GSa/s) or 5 GHz (at 10 GSa/s)
Frequency resolution	Resolution = sample rate/memory depth
Window modes	Hanning, flattop, rectangular , Blackman Harris, Force

² Requires MATLAB software.

Trigger modes

Edge (analog and digital)	Triggers on a specified slope (rising, falling or alternating between rising and falling) and voltage level on any channel.
Edge transition (analog)	Trigger on rising or falling edges that cross two voltage levels in > or < the amount of time specified. Edge transition setting from 250 ps.
Edge then edge (time) (analog and digital)	The trigger is qualified by an edge. After a specified time delay between 10 ns to 10 s, a rising or falling edge on any one selected input will generate the trigger.
Edge then edge (event) (analog and digital)	The trigger is qualified by an edge. After a specified delay between 1 to 16,000,000 rising or falling edges, another rising or falling edge on any one selected input will generate the trigger.
Glitch (analog and digital)	Triggers on glitches narrower than the other pulses in your waveform by specifying a width less than your narrowest pulse and a polarity. Glitch range settings equal pulse width settings
Line	Triggers on the line voltage powering the oscilloscope.
Pulse width (analog and digital) 4 GHz model	Trigger on a pulse that is wider or narrower than specified. Minimum detectable pulse width: 125 ps for analog channels, 1 ns for digital channels. Pulse width range settings: 250 ps to 10 s for analog channels, 2 ns to 10 s for digital channels.
2.5 GHz model	Minimum detectable pulse width: 200 ps for analog channels, 1 ns for digital channels. Pulse width range settings: 350 ps to 10 s for analog channels, 2 ns to 10 s for digital channels.
1 GHz and 600 MHz model	Minimum detectable pulse width: 500 ps for analog channels, 1 ns for digital channels. Pulse width range settings: 700 ps to 10 s for analog channels, 2 ns to 10 s for digital channels.
Runt (analog)	Triggers on a pulse that crosses one threshold but fails to cross a second threshold before crossing the first again. Runt settings equal pulse width settings.
Timeout (analog and digital)	Trigger when a channel stays high, low, or unchanged for too long. Timeout settings equal pulse width settings.
Pattern/pulse range (analog and digital)	Triggers when a specified logical combination of the channels is entered, exited, present for a specified period of time or is within a specified time range or times out. Each channel can have a value of High (H), Low (L) or Don't care (X).
State (analog and digital)	Pattern trigger clocked by the rising, falling or alternating between rising and falling edge of one channel.
Setup/hold (analog)	Triggers on setup, hold, or setup and hold violations in your circuit. Requires a clock and data signal on any two inputs (except aux or line) channels as trigger sources. Setup and/or hold time must then be specified.
Window (analog)	Trigger on entering, exiting, or inside specified voltage range
Video (analog)	NTSC, PAL-M(525/60), PAL, SECAM(625,50) EDTV(480p/60), EDTV(576/50), HDTV(720p/60), HDTV(720p/50) HDTV(1080i/60)
Serial (analog and digital)	Requires specified serial software option, I ² C, SPI, CAN, LIN,FlexRay, RS-232/UART, JTAG, USB, PCIe, MIPI D-Phy, generic 8B/10B
Zone-qualified	Requires InfiniiScan software option. SW-based triggering across up to 8 user-drawn zones. For each zone, user specifies "must intersect" or "must not intersect." Zones can be drawn on multiple channels and combined using Boolean expressions.

Display

Display	15 inch color XGA TFT-LCD with touch screen			
Display intensity grayscale	64-level intensity-graded display			
Resolution	1024 pixels horizontally x 768 pixels vertically			
Annotation	Up to 12 labels, with up to 100 characters each, can be inserted into the waveform area			
Grids	Can display 1, 2 or 4 waveform grids			
Waveform styles	Connected dots, dots, variable persistence, infinite persistence, color graded infinite persistence. Includes up to 64 levels of intensity-graded waveforms.			
Waveform update rate	Segmented mode: Maximum up to 250,000 waveforms/sec			
(10 GS/s, 50 ns/div, sin(x)/x: on)	Real time mode Maximum of 4,000 waveforms/sec.			
	Typical of 2,100 waveforms/sec with 1kpts memory.			
	Typical of 420 waveforms/sec with 100 kpts memory			
	Typical of 400 waveforms/sec with 1 Mpts memory			
	Typical of 300 waveforms/sec with 10 Mpts			

Computer system and peripherals, I/O ports

Computer system and peripherals		
Operating system	Windows 7 Embedded Standard	
CPU	Intel® Core 2 Duo, M890, 3.0 GHz microprocessor	
PC system memory	4 GB	
Drives	≥ 250-Gb internal hard drive (optional removable hard drive), external DVD-RW drive (optional)	
Peripherals	Optical USB mouse and compact keyboard supplied. All Infiniium models support any Windowscompatible input device with a PS/2 or USB interface.	
File types		
Waveforms	Compressed internal format (*.wfm), comma separated values (*.csv), .hdf5, .bin, tab separated values (*.tsv), ability to save .osc (composite including both setup and waveform.	
	and Y value files (*.txt)	
Images	BMP, TIFF, GIF, PNG or JPEG	
I/O ports		
LAN	RJ-45 connector, supports 10Base-T, 100Base-T, and 1000Base-T. Enables Web-enabled remote control, e-mail on trigger, data/file transfers and network printing.	
RS-232 (serial)	9-pin, COM1, printer and pointing device support	
PS/2	Two ports. Supports PS/2 pointing and input devices.	
USB 2.0 Hi-Speed	Three 2.0 high-speed ports on front panel plus four ports on side panel. Allows connection of USB peripherals like storage devices and pointing devices while the oscilloscope is on. One device port on side for instrument control	
Video output	15 pin XGA on side of scope, full output of scope display or dual monitor video output, DVI	
Auxiliary output	DC (\pm 2.4 V); square wave ~755 Hz with ~200 ps rise time.	
Time base reference output	10 MHz, Amplitude into 50 ohms: 800 mV pp to 1.26 V pp (4 dBm \pm 2 dB) if derived from internal reference. Tracks external reference input amplitude \pm 1 dB if applied and selected.	
Time base reference input	Must be 10 MHz, input Z = 50 ohms. Minimum 500 mV pp (–2 dBm), maximum 2.0 V pp (+10 dBm).	
LXI compliance	LXI Class C	

General characteristics

5 °C to + 40 °C	
-40 °C to + 65 °C	
Up to 95% relative humidity (non-condensing) at +40 °C	
Up to 90% relative humidity at +65 °C	
Up to 4,000 meters (12,000 feet)	
Up to 15,300 meters (50,000 feet)	
Random vibration 5-500 Hz, 10 minutes per axis, 0.3 g (rms)	
Random vibration 5-500 Hz, 10 minutes per axis, 2.41 g (rms); resonant search 5-500 Hz, swept sine	
1 octave/minute sweep rate, (0.75 g), 5 minute resonant dwell at 4 resonances per axis	
100-120 V, ± 10% 50/60/400 Hz	
100-240 V, ± 10% 50/60 Hz	
Max power dissipated: 375 W	
30 dB at front of instrument	
Net: 11.8 kg (26 lbs.) Shipping: 17.8 kg (39 lbs.)	
Height: 12.9 in (33 cm); width: 16.8 in (43 cm); depth: 9 in (23 cm)	
Meets IEC1010-1 Second Edition, certified to UL61010-1 and CAN/CSA-C22.2 No 61010-1 Second Edition (IEC61010-1:2001, MOD).	

Infiniium 9000 Series ordering information

How to configure an Infiniium 9000 Series

- 1. Choose needed bandwidth
- 2. Choose MSO or DSO
- 3. Choose desired software applications
- 4. Choose memory depth upgrade
- 5. Choose any additional probes and accessories

Accessories included:

All models ship standard with: 1-year warranty, four N2873A 500 MHz passive probes, probe accessory pouch (mounts on rear of instrument), Agilent I/O libraries suite 15.0, localized power cord, front panel cover, keyboard, mouse, and stylus. User guide and programmer's guide ship on oscilloscope hard drive. Service guide available on Agilent.com. MSO models additionally ship with channel flying lead set logic probe, MSO cable and calibration fixture.


Model	Analog bandwidth	Analog sample rate* (4 ch / 2 ch)	Standard memory* (4 ch / 2 ch)	Scope channels	Logic channels
DS09064A	600 MHz	5 GSa/s / 10 GSa/s	20 Mpts / 40 Mpts	4	-
MS09064A	600 MHz	5 GSa/s / 10 GSa/s	20 Mpts / 40 Mpts	4	16
DS09104A	1 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	-
MS09104A	1 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	16
DS09254A	2.5 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	-
MS09254A	2.5 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	16
DS09404A	4 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	-
MS09404A	4 GHz	10 GSa/s / 20 GSa/s	20 Mpts / 40 Mpts	4	16

^{*} In 2-channel mode, maximum sample rate and memory depth double.

Additional options and accessories		
Option A6J	ANSI Z540 compliant calibration	
DSO9000A-820	External DVD-RW with USB connection	
N2902A or Option 1CM (8U)	9000 Series oscilloscope rackmount kit	
Option 801	Removable solid state drive	
N2746A (requires Option 801)	Additional solid state drive Windows 7	
Gemstar 5000 custom-molded case	Available from www.gemstarmfg.com	
N2918B	Infiniium 9000 Series Evaluation Kit	
N4865A	GPIB to LAN adapter	



Quickly remove your solid state drive for additional security with Option 801.



Mount your 9000 Series scope in an 8U high, 19" (487mm) wide rack with option ICM.

Infiniium 9000 Series ordering information

RS-232/UART triggering and decode	SW Applications	Factory-installed option for new scope purchases	User-installed stand-alone product number	User-installed floating license (N5435A option)
High speed SDA and clock recovery	RS-232/UART triggering and decode	001	N5462B	031
EZJIT Plus jitter analysis software	EZJIT jitter analysis software	002	E2681A	002
USB triggering and decode 006 N5463B 032 PCI Express 1.1 triggering and decode 006 N5463B 032 PC/CSPI triggering and decode 007 N5391B 006 CAN, LIN, and FlexRay triggering and decode 008 N8803B 033 InfiniScan 009 N5415B 004 User-defined function 010 N5430A 005 Application remote programming interface 011 N5452A	High-speed SDA and clock recovery	003	N5384A	003
PCI Express 1.1 triggering and decode 006 N5463B 032 PC/SPI triggering and decode 007 N5391B 006 CAN, LIN, and FlexRay triggering and decode 008 N8803B 033 InfiniiScan 009 N541BB 004 User-defined function 010 N5430A 005 Application remote programming interface 011 N5452A	EZJIT Plus jitter analysis software	004	N5400A	001
PC/SP triggering and decode	USB triggering and decode	005	N5464B	034
CAN, LIN, and FlexRay triggering and decode 008 N8803B 033 InfinitiScan 009 NS415B 004 User-defined function 010 N5430A 005 Application remote programming interface 011 NS462A Temperature InfiniiSim signal equalization 012 N5461A 025 InfiniiSim basic signal de-embedding 013 NS465A 001 026 InfiniiSim advanced signal de-embedding 014 NS465A 002 027 Power measurement application software 015 U1882A Temperature Xilinx PFOA dynamic probe 016 NS397A Temperature Altera FPGA dynamic probe 017 NS433A Temperature RS-232, SPI and I'C triggering and decode bundle 018 N8800B Temperature MIPI D-Phy Triggering and decode bundle 018 N8802A 036 USB2,0 compliance 021 NS392A 008 USB2,0 compliance 031 U7233A 021 DDR1 and LPDDR compliance 031 U7233A 021 </td <td>PCI Express 1.1 triggering and decode</td> <td>006</td> <td>N5463B</td> <td>032</td>	PCI Express 1.1 triggering and decode	006	N5463B	032
InfiniScan 009 N5415B 004 User-defined function 010 N5430A 005 Application remote programming interface 011 N5452A InfiniiSim signal equalization 012 N5461A 025 InfiniiSim signal de-embedding 013 N5465A 001 026 InfiniiSim advanced signal de-embedding 014 N5465A 002 027 Power measurement application software 015 U1882A Xilinx PFGA dynamic probe 016 N5397A H Altera FFGA dynamic probe 016 N5397A H RS-232, SPI and l°C triggering and decode bundle 018 N8800B U17 MIPI D-Phy Triggering and decode 019 N8802A 036 Ethernet compliance 021 N5332A 008 USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020	I ² C/SPI triggering and decode	007	N5391B	006
User-defined function	CAN, LIN, and FlexRay triggering and decode	008	N8803B	033
Application remote programming interface	InfiniiScan	009	N5415B	004
Infinisism signal equalization 012	User-defined function	010	N5430A	005
InfiniSim basic signal de-embedding	Application remote programming interface	011	N5452A	
InfiniiSim advanced signal de-embedding	InfiniiSim signal equalization	012	N5461A	025
Power measurement application software	InfiniiSim basic signal de-embedding	013	N5465A 001	026
Xilinx FPGA dynamic probe 016 N5397A	InfiniiSim advanced signal de-embedding	014	N5465A 002	027
Altera FPGA dynamic probe 017 N5433A RS-232, SPI and I³C triggering and decode bundle 018 N8800B MIPI D-Phy Triggering and decode 019 N8802A 036 Ethernet compliance 021 N5392A 008 USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB basic 061 MATLAB davanced 062 HDM1 1.4 (up to 740 Mbp/s) N5399B 10GBase-7 Ethernet compliance 064 N645A 061 BroadR-Reach compliance 065 N6467A 062	Power measurement application software	015	U1882A	
RS-232, SPI and I²C triggering and decode 019 N8800B MIPI D-Phy Triggering and decode 019 N8802A 036 Ethernet compliance 021 N5392A 008 USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A 047 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047	Xilinx FPGA dynamic probe	016	N5397A	
MIPI D-Phy Triggering and decode 019 N8802A 036 Ethernet compliance 021 N5392A 008 USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A U54 JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet complianc	Altera FPGA dynamic probe	017	N5433A	
Ethernet compliance 021 N5392A 008 USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A U7248 JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB davanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 <	RS-232, SPI and I ² C triggering and decode bundle	018	N8800B	
USB2.0 compliance 029 N5416A 017 DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A 035 USB HSIC compliance test 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB davanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061	MIPI D-Phy Triggering and decode	019	N8802A	036
DDR1 and LPDDR compliance 031 U7233A 021 DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A U7248 JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A E2625A MATLAB basic 061 N5399B MATLAB advanced 062 U7236A HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance <td>Ethernet compliance</td> <td>021</td> <td>N5392A</td> <td>008</td>	Ethernet compliance	021	N5392A	008
DDR2 and LPDDR2 compliance 032 N5413B 016 DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A 038 JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A E2625A MATLAB basic 061 062 MATLAB advanced 062 U7236A HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	USB2.0 compliance	029	N5416A	017
DDR3 compliance 033 U7231A 020 MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A USB GIEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A E2625A MATLAB basic 061 N5399B MATLAB advanced 062 U7236A HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	DDR1 and LPDDR compliance	031	U7233A	021
MIPI D-Phy compliance 035 U7238A 022 SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A US467A JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A E2625A MATLAB basic 061 N5399B HDMI 1.4 (up to 740 Mbp/s) N5399B U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	DDR2 and LPDDR2 compliance	032	N5413B	016
SATA1 (1.5 GB/s triggering and decode) 038 N8801A 035 User definable application 040 N5467A	DDR3 compliance	033	U7231A	020
User definable application 040 N5467A JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	MIPI D-Phy compliance	035	U7238A	022
JTAG (IEEE 1149.1) triggering and decode 042 N8817A 038 USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	SATA1 (1.5 GB/s triggering and decode)	038	N8801A	035
USB HSIC compliance test 043 U7248 042 DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	User definable application	040	N5467A	
DigRF protocol decode 045 N8807A 047 SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	JTAG (IEEE 1149.1) triggering and decode	042	N8817A	038
SVID protocol triggering and decode 046 N8812A 054 Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	USB HSIC compliance test	043	U7248	042
Communication mask test kit E2625A MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	DigRF protocol decode	045	N8807A	047
MATLAB basic 061 MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	SVID protocol triggering and decode	046	N8812A	054
MATLAB advanced 062 HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	Communication mask test kit		E2625A	
HDMI 1.4 (up to 740 Mbp/s) N5399B 10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	MATLAB basic	061		
10GBase-T Ethernet compliance U7236A Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	MATLAB advanced	062		
Precision Probe N2808A 044 eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	HDMI 1.4 (up to 740 Mbp/s)		N5399B	
eMMC compliance 064 N6465A 061 BroadR-Reach compliance 065 N6467A 062	10GBase-T Ethernet compliance		U7236A	
BroadR-Reach compliance 065 N6467A 062	Precision Probe		N2808A	044
·	eMMC compliance	064	N6465A	061
MOST compliance 073 N6466A 068	BroadR-Reach compliance	065	N6467A	062
	MOST compliance	073	N6466A	068

Upgrades

Memory upgrade

Memory per scope channel (4-channel/ 2-channel mode)	Factory-installed option for new scope purchases	User-installed option (N2900A)
20 Mpts/40 Mpts	Standard	020
50 Mpts/100 Mpts	50M	050
100 Mpts/200 Mpts	100	100
200 Mpts/400 Mpts	200	200
500 Mpts/1 Gpts	500	500

DS0 to MS0 upgrades

(N2901A/B/C/D)

Upgrade your existing DSO to an MSO model in 5 minutes. The upgrade kit turns on all MSO capability and includes an MSO cable, 16-channel lead set with grabbers, an MSO-enabled sticker, and a digital-analog deskew fixture.

Post-sales upgrades

DSO → MSO upgrades		
N2901D	DS09064A to MS09064A Upgrade Kit	
N2901A	DS09104A to MS09104A Upgrade Kit	
N2901B	DS09254A to MS09254A Upgrade Kit	
N2901C	DS09404A to MS09404A Upgrade Kit	

Oscilloscopes bandwidth upgrades			
N2905A	Upgrade to 2.5 GHz bandwidth	-option 006 600 MHz to 2.5 GHz -option 010 1 GHz to 2.5 GHz	
N2904A	Upgrade to 4.0 GHz bandwidth	-option 006 600 MHz to 4 GHz -option 010 1 GHz to 4 GHz -option 025 2.5 GHz to 4 GHz	

Additional acquisition memory

(N2900A or options 50, 100, 200, and 500 on new scope purchase)

Increase memory depth to capture longer time periods and maintain faster speeds. Memory depth doubles in 2-channel mode.

Memory depth upgrades		
N2900A	Depth doubles in 2 channel mode.	-option 050 upgrade to 50 Mpts/ch -option 100 upgrade to 100 Mpts/ch -option 200 upgrade to 200 Mpts/ch -option 500 upgrade to 500 Mpts/ch

Operating system upgrades		
N2753A	Windows 7 for Infiniium 9000 scope with Windows XP and SN>MY50410100	
N2754A	Window 7 and M890 motherboard for Infiniium 9000 scopes with Windows XP and SN <my50410100< td=""></my50410100<>	





www.agilent.com/find/myagilent

A personalized view into the information most relevant to you.



www.lxistandard.org

LAN eXtensions for Instruments puts the power of Ethernet and the Web inside your test systems. Agilent is a founding member of the LXI consortium.

Agilent Channel Partners

www.agilent.com/find/channelpartners

Get the best of both worlds: Agilent's measurement expertise and product breadth, combined with channel partner convenience.



Three-Year Warranty

www.agilent.com/find/ThreeYearWarranty

Agilent's combination of product reliability and three-year warranty coverage is another way we help you achieve your business goals: increased confidence in uptime, reduced cost of ownership and greater convenience.



Agilent Advantage Services

www.agilent.com/find/AdvantageServices

Accurate measurements throughout the life of your instruments.



www.agilent.com/quality

PCI Express and PCIe are registered trademarks of PCI-SIG.

MATLAB is a U.S. registered trademark of The MathWorks, Inc.



Agilent Technologies Oscilloscopes

Multiple form factors from 20 MHz to > 90 GHz | Industry leading specs | Powerful applications

www.agilent.com www.agilent.com/find/9000

For more information on Agilent Technologies' products, applications or services, please contact your local Agilent office. The complete list is available at: www.agilent.com/find/contactus

Americas

Canada	(877) 894 4414
Brazil	(11) 4197 3600
Mexico	01800 5064 800
United States	(800) 829 4444

Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 375 8100

Europe & Middle East

Europe & willule cast	
Belgium	32 (0) 2 404 93 40
Denmark	45 45 80 12 15
Finland	358 (0) 10 855 2100
France	0825 010 700*
	*0.125 €/minute
Germany	49 (0) 7031 464 6333
Ireland	1890 924 204
Israel	972-3-9288-504/544
Italy	39 02 92 60 8484
Netherlands	31 (0) 20 547 2111
Spain	34 (91) 631 3300
Sweden	0200-88 22 55
United Kingdom	44 (0) 118 927 6201

For other unlisted countries: www.agilent.com/find/contactus (BP2-19-13)

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2012, 2013 Published in USA, May 3, 2013 5990-3746EN

